



Installation instructions

A336, A337, A338 Space-saving Coat Hooks

Installation

A **competent carpenter or maintenance person** should install your Space-saving Coat Hooks.

- Attach the Coat Hooks to the wall with at least four fasteners (as shown in the image below). Use fasteners that are suitable for the wall construction and the weight of the fully loaded item (fasteners are not included in the delivery).
- Holes should be pre-drilled through the Coat Hook back panel for the fasteners to pass through.
- Once you have finished, make sure that the fixings safely support the weight of the fully loaded Coat Hooks.

⚠ WARNING

The Coat Hooks must be properly mounted to a wall before use.
It is the customer's responsibility to ensure that the item is securely attached.

Recommended mounting heights:

Age of child (years)	2	3	4	5	6
Recommended height to bottom of unit	75 cm	81 cm	87 cm	92 cm	99 cm

