



Product guide

J641, J651 Child's sofa and armchair

IMPORTANT

Save these instructions for reference

Recommended use

This sofa and armchair are designed for general childcare or classroom use. This product is suitable for children age 2–8 years.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement; therefore, adult supervision is required at all times.
- ▲ Weight limit: 180 kg

⚠ CAUTION

- ▲ For indoor use only. The sofa and armchair are not waterproof.

Maintenance

Periodically inspect for cracks, breaks, loose parts, loose screws, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make use unsafe.

Construction

The wooden components are manufactured from hardwood and finished with a clear wood finish. All edges and corners are rounded for safety and ease of cleaning. The upholstery is CMHR polyurethane foam covered with a highly durable and stain resistant silicone coated fabric. The upholstery complies with Furniture and Furnishings (Fire)(Safety) Regulations 1988 as well as BS 7176 Medium Hazard Category.

Cleaning

Wipe clean with a soft cloth and warm water, using your standard detergent. Safe antibacterial surface cleansers can also be applied. Rinse off all cleaning agents and disinfectants and dry with a cloth. Do not machine wash, as seams are not waterproof.

User modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing, or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.

