



Product guide

H551, H552, H553, H554 H577, H587, H578, H588, H573, H583, H574, H584 Art supplies storage

IMPORTANT

Save these instructions for reference

Recommended Use

These items are intended for the storage and display of arts and craft materials. They may also be used in other interest areas for other items e.g. maths and sciences. These counter tops can be used with craft shelves or roomscape shelving.

Products consist of the following:

H551 Paper Corner

H552 Tool Corner Includes 5 green cups

H553 Craft Counter Top 3 includes 1 Paper corner, 1 Tool corner, 5 cups, 2 medium totes, 2 small totes, and 1 dowel

H554 Craft Counter Top 4 includes 1 Paper corner, 1 Tool corner, 5 cups, 4 medium totes, 4 small totes, and 1 dowel

If your shipment is incomplete, please call Customer Service. All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.

WARNING

▲ These products are intended for use by children of immature judgment, therefore supervision is required at all times.

CAUTION

▲ For indoor use only. These products are not waterproof.

Maintenance

Periodically inspect for cracks, breaks and loose or missing parts. Remove Products from service when any condition develops that might make operation unsafe.

Cleaning

Wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish.

Construction

The wooden components are manufactured from solid birch and birch plywood protected with a child-safe finish. The cups and totes are plastic.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Assembly

To attach Craft counter tops to Craft shelves

(requires 2 people, see Figure A):

1. Line up the counter above the shelf.
2. Lower the counter down until the back of the shelf is behind the back of the counter.

To attach Craft counter tops to Roomscapes units

(requires 2 people, see Figure B):

1. Hook the front of the counter over the front edge of the Roomscapes unit.
2. Rotate the counter down over the back of the Roomscapes unit.

The Paper corner and the Tool corner locate on "bumps" on the Craft counter top. Do not locate Paper corner and Tool corner until Craft counter top is properly in place.

CAUTION

▲ Only rearrange items when Craft counter top is empty. Use hand-holds provided. Do not rearrange units with children nearby.




Figure A




Figure B

▲ Lift with 2 people where necessary.

▲ Do not attach Craft counter tops to 102cm high Roomscapes furniture.

▲ Only attach Craft counter tops to Roomscapes furniture of the same length.

▲ Craft counter tops are not intended to be used on a table.

Ordering parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.