



Product guide

F411, F412, F413, F414, F441, F442, F443, F444, F401, F402, F403, F404
Montessori shelving

IMPORTANT

Save these instructions for reference

Recommended use

These shelving units are designed to be used together.

⚠ WARNING

▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only.

Operation of mobility feature on straight shelving

The mobility feature can be easily engaged and disengaged using the following procedure:

1. With one person at each end of the unit, tip slightly forward or back. This allows the toe trim to pivot.
2. One person keeps the item tipped, while the other rotates the toe trim to the desired position by pulling or pushing on one of the handholds at each end of the toe trim (see Figure A).
3. Tip the unit slightly to the other side and repeat the procedure with the other toe trim.




Figure A

⚠ CAUTION

- ▲ Never change the position of the toe trim with less than two people.
- ▲ Always use the handholds provided at each end of the toe trim (see Figure A).
- ▲ After disengaging the wheels, give item a small sideways push to settle the wheels into place. You will notice the item sitting down securely on its glides.

All these shelves are 71 cm high.

F441 124 cm closed back, with one shelf

F442 124 cm open back, with one shelf

F413 Open sweep shelf with one shelf

F411 Corner shelf with one shelf

F443 124 cm closed back, with two shelves

F444 124 cm open back, with two shelves

F414 Open sweep shelf with two shelves

F412 Corner shelf with two shelves

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Construction

Shelves are manufactured from solid birch and have hardwood plywood backs protected with a child-safe finish.

Cleaning

Wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.

All of our packaging is recyclable (cardboard and LDPE).

Please recycle in accordance with local guidelines.