

Product guide

W456, W457 Outlast kitchen, counter and sink

IMPORTANT

Save these instructions for reference

Recommended use

The Outlast classic mud kitchen provides a setting for open ended outdoor role play. The Classic sink provides a contained play area. The attached backsplash helps define the play space and doubles as a storage surface.

Outlast scoops clip handily onto the backsplash. The sturdy non-removable sink has a contoured basin and large drain to allow it to empty completely. The rubber plug is permanently attached.

For ages 3 to 5.

A WARNING

- This product is intended for use by children of immature judgement. Supervision is required at all times.
- Water is a drowning hazard. Do not leave sink full of water unattended.

A CAUTION

▲ Adults are responsible to prevent these products from being used by children in unsafe combinations with other components. Make sure the unit is sitting securely on the ground.

Assembly:

Your Outlast classic mud kitchen item comes fully assembled and ready to use. Classic counter includes 1 Crate and 4 Nature trays. Classic sink includes 1 Crate, 2 Nature trays, and 3 Kitchen scoops.

If your shipment is incomplete, please call customer service. All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.

Accessories:

W446 Nature tray -

A small tray that can be used for handy storage or loose parts play. **W444** Kitchen scoop set -

A set of sturdy plastic scoops that can clip to back of sink or crates.

Cleaning:

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a disinfectant solution such as Milton Sterilising Fluid.

Maintenance:

Acetylated wood weathers to a natural silver grey if left untreated outdoors. If you prefer the original look, scrub with a mild detergent or disinfectant solution. When dry, apply a tinted, nontoxic penetrating stain. Refinishing stain is available from customer service.

Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service if any condition develops that might make operation unsafe.

Construction:

The wooden components are manufactured from long lasting acetylated wood and finished with a water based stain. All edges and corners are rounded for safety and ease of cleaning. End grain is protected by plastic guards. Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in outdoor environments.

User modifications:

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Ordering parts:

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.

Community Playthings, Brightling Road, Robertsbridge, TN32 5DR communityplaythings.co.uk • sales@communityplaythings.co.uk • 0800 387 457 © 2019 by Community Products (UK) Ltd • FD62 Eu 0709 Revision 01

#