



Product guide

H220, H221 Workbench

IMPORTANT

Save these instructions for reference

Recommended use

The Workbench provides a solid work area for real projects. It is suitable for children from 3 – 6 years.

Maximum load on the working surface: 200 Kg

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Safety glasses must be worn whenever tools are in use.
- ▲ When the Tool cabinet is used, ensure it is properly latched to the Workbench with the locking handles in the "down" position.
- ▲ The workbench comes with two real vices which can apply pressure to fingers and other parts of the body! Keep fingers away from the clamping area. Protruding work pieces may cause overturning. (NOTE: If not required, the vices can be removed to eliminate this hazard.)

⚠ CAUTION

- ▲ To move workbench safely, remove all accessories and lift with two adults.

Assembly

Make sure all components of your workbench arrived in good condition. If any parts are broken or missing, call customer service.

H220 Basic workbench includes 2 Vices

H221 Complete workbench includes:

- 2 Vices
- H227 Tool cabinet
- H226 Workbench storage

There are three vice mounting locations on each workbench. Insert the guide rods into the mounting block until the vice screw engages and turn the handle until the vice is closed.

⚠ CAUTION

- ▲ Close vices when not in use.

If your shipment is incomplete, please call customer service. All the packaging from this product is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.

Accessories

H226 Workbench storage includes shelf and two carry crates.

H227 Tool cabinet includes clear cover and 6 containers.

H228 Tool set includes saw, hammer, file, 2 screwdrivers, and 2 pairs of safety glasses.

⚠ WARNING

- ▲ The tools are real tools, not toys.

Maintenance

Apply 3-In-ONE or other multi-purpose oil to the vice screws once a year. Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Cleaning

Wooden components: Wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish.

Clear cover: Dust and clean with a soft cloth to avoid scratching. Use a mild detergent. Dry by blotting with a cloth.

Construction

Wooden components are manufactured from solid birch or birch plywood and are protected with a child-safe finish.

Vice is made of steel and solid birch.

Clear cover is Perspex.

Tools are steel with rubber handgrips.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.