



Product guide

A303, A333, A304 Wall-mounted storage shelf

IMPORTANT

Save these instructions for reference

Recommended use

The Wall-mounted storage shelf provides extra storage space, and fit up to eight, six, or four Community Playthings deep totes, deep baskets or medium carry crates on the A304, A333, or A303 respectively.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement, therefore supervision is required at all times.
- ▲ The Wall-mounted storage shelf must be properly mounted to a wall before use. It is the customer's responsibility to ensure that the item is securely attached.
- ▲ For indoor use only.

Installation

To install the Wall-mounted storage shelf refer to the product installation instructions.

Maintenance

Periodically inspect for secure connections, cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Construction

The Wall-mounted storage shelf is made from solid birch protected with a child-safe finish.

Cleaning

Wipe with a damp cloth and mild detergent. Do not use excessive water.

User modifications

We recognize that some users might benefit from modifications made in the field. However, we are not responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product. **Use only replacement parts supplied by Community Playthings.**

If your shipment is incomplete, please call customer service.

All the packaging from this product is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.

