



Product guide

H559 Peg tree

IMPORTANT

Save these instructions for reference

Recommended use

The Peg tree provides hanging space for aprons, dress-ups, hats, bags and extra clothing.

For ages 2 to 8.

⚠ WARNING

▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only. The Peg tree is not waterproof.

Assembly

The Peg tree comes in 2 parts (see figure A): the stand and the post. To assemble the Peg tree, refer to the following steps:

1. Insert the slotted end of the post into the stand
2. Tap the stand and post on the floor
3. Ensure that the post is firmly engaged into the stand.

If your shipment is incomplete, please call customer service.

All of our packaging is recyclable (cardboard and LDPE).

Please recycle in accordance with local guidelines.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Construction

The wooden components are manufactured from solid birch and birch plywood, protected with a child-safe finish.

Cleaning

Wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.




Figure A