



Product guide

W385, W386, W387, W388 Outlast blocks and ramps

IMPORTANT

Save these instructions for reference

Recommended use

The Outlast blocks and ramps are intended to support outdoor, active and cooperative play. Blocks are designed for use on any level surface including grass and dirt. However when using them on hard or abrasive surfaces such as tarmac we recommend using rubber mats so your blocks last as long as possible. Their interlocking design allows for many useful and creative structures, limited only by your children's imagination. The ramps enhance the play value of blocks and can be used in water play. They come in two sizes and are compatible with Outlast blocks.

For ages 3 and older.

Construction

The wooden components are manufactured from long-lasting acetylated wood and finished with a nontoxic stain. All edges and corners are rounded for safety and ease of cleaning.

Stainless steel hardware is used throughout and all end grain is protected by UV-resistant plastic guards formulated to ensure long life in outdoor environments.

Assembly

Outlast blocks and ramps come fully assembled. Use the charts here to determine if your shipment is complete: communityplaythings.co.uk/OLBC

⚠ WARNING

- ▲ Outlast blocks and ramps are intended to let children experiment with balance and stability, and to learn to manage risk. Ensure adequate free space around the Outlast block play area. Unstable structures may topple and could cause injury, therefore supervision is required at all times.
- ▲ Children should not build structures above their shoulder height.
- ▲ Children must not be allowed to climb on structures with a height of 60cm high or more.
- ▲ Beware of unsafe block structures.

⚠ CAUTION

- ▲ Long Blocks and Planks are heavy. Encourage cooperation to prevent injury.
- ▲ To prevent injury, caregivers and staff must familiarize themselves with these materials before giving children access to them.

Maintenance

Outlast blocks can be left outside all year around and do not require covered storage. Acetylated wood weathers to a natural silver grey if left untreated outdoors. If you prefer the original look, scrub with a mild detergent or disinfectant solution. When dry, apply a tinted, nontoxic penetrating stain. Refinishing stain is available from customer service.

Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service if any condition develops that might make operation unsafe.

Cleaning

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a disinfectant solution such as Milton Sterilising Fluid.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.

If your shipment is incomplete, please contact customer service. All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.