



Product guide

H555, H556 Craft shelf

IMPORTANT

Save these instructions for reference

Recommended use

These items are intended for the storage and display of arts and craft materials. They may also be used in other interest areas for other items e.g. maths and sciences. They can be used with the Craft counter tops.

⚠ WARNING

▲ These products are intended for use by children of immature judgment, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only. These products are not waterproof.

H575 Craft shelf 3 with totes or baskets includes:

- 1 H555 Craft shelf 3
- 6 Deep totes or 6 Deep baskets in a separate carton

H576 Craft shelf 4 with totes or baskets includes:

- H556 Craft shelf 4
- 8 Deep totes, or 8 Deep baskets in a separate carton

If your shipment is incomplete, please call customer service.

Accessories

Roomscapes posts are available to connect Craft shelves to other Roomscapes items

Maintenance

Periodically inspect for cracks, breaks and loose or missing parts. Remove products from service if any condition develops that might make operation unsafe.

Cleaning

Wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish.

Construction

The wooden components are manufactured from solid birch and birch plywood protected with a child-safe finish.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Connection to Roomscapes items

Craft shelves can be connected to Roomscapes posts, panels, and furniture. The posts attach to the plastic couplings that are on the sides of the units.

For more information on the Roomscapes connecting system, see the Roomscapes product guide F601 supplied by Community Playthings with every Roomscapes order.

Mobility

It is important to understand how to operate the mobility feature, which can be easily engaged and disengaged using the following procedure:

1. With one person at each end of the unit, tip unit slightly forward or back, allowing the toe trim to pivot.
2. One person keeps the item tipped, while the other rotates the toe trim to the desired position by pulling or pushing on one of the handholds at each end of the toe trim (Figure A).
3. Tip the unit slightly to the other side and repeat the procedure with the other toe trim.




Figure A

⚠ CAUTION

- ▲ Never change the position of the toe trim with less than two people.
- ▲ Always use the handholds provided at each end of the toe trim (Figure A).
- ▲ After disengaging the wheels, give the item a small sideways push to settle the wheels into place. You will notice the item sitting down securely on its glides.
- ▲ Never adjust mobility with children near by.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.

All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.