



Product guide

C965, C985, C994, C950, C990, C991, C992, C993 C912, C913, C914, C916, C917, C918, C923, C924 ToddleBoxes

IMPORTANT

Save these instructions for reference

Recommended use

ToddleBoxes support physical development and learning. Units engage with connectors for stability under active play. ToddleBoxes can be used either way up.

For ages 9 to 36 months.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.
- ▲ Do not stack while in use.

⚠ CAUTION

- ▲ For indoor use only. These products are not waterproof.

Connection

Each ToddleBox unit comes with a connector (Fig A) that will prevent rearranging of the units by children, and enhance stability. Configuration of the ToddleBoxes should be done by an adult.




Figure A

- Use Connectors to join ToddleBoxes together.
- The Steering wheel may be connected to the ToddleBoxes.
- When connecting ToddleBoxes you may have to assemble the configuration upside down in order to access the connecting slots. When the configuration is complete, turn the assembly over, with an assistant.
- When the Hill is used as a rocking boat, it should not be connected to any other boxes.

Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Construction

The wooden components are manufactured of solid birch and plywood with a child-safe finish.

Cleaning

Wipe wooden parts with a damp cloth and mild detergent. Too much water will harm the finish of the wood. Dry the wood components after cleaning.

Carpets are removable. Carpet can be professionally cleaned. Do not soak carpets to remove stains, dirt or other grime. Do not use excessive water. Periodically vacuum carpets.

User modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product.

Use only replacement parts supplied by Community Playthings.

All of our packaging is recyclable (cardboard and LDPE).

Please recycle in accordance with local guidelines.