



Product guide

A306, A307, A308, A309, A311, A331, A312 Benches

IMPORTANT

Save these instructions for reference

Recommended use

Benches provide tidy storage for children's footwear, and are suitable for adults to sit on as they assist children.

⚠ WARNING

▲ This product is intended for use by children of immature judgement, therefore supervision is required at all times.

⚠ CAUTION

▲ For indoor use only.

Maintenance

Periodically inspect for secure connections, cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service if any condition develops that might make operation unsafe.

Construction

Benches are made from solid birch protected with a child-safe finish.
Grates are made from durable plastic.

Cleaning

Wooden parts: Wipe with a damp cloth and mild detergent. Do not use excessive water.

Plastic parts: Dust with a soft, damp cloth. Wash with dishwashing detergent and plenty of lukewarm water.

User modifications

We recognize that some users might benefit from modifications made in the field. However, we are not responsible for modifications made by customers to our products in the field without our supervision, testing or evaluation.

Ordering parts

To order replacement parts, contact customer service with a description of the part(s) needed and the ID code from the product. **Use only replacement parts supplied by Community Playthings.**

If your shipment is incomplete, please call customer service.

All the packaging from this product is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.