



# Product guide

W303,W304 Outlast storage unit

## IMPORTANT

Save these instructions for reference

### Recommended use

The Outlast storage unit is intended for the storage of children's play equipment at the point of use. Designed to house the Outlast crates and Outlast blocks, this unit allows children to help with clean-up. This unit can be placed on any reasonably level area. Once levelled with levelling pads (provided) and built-in adjustable feet, it is ready for use.

The door latch can be locked with a 6-8 mm padlock with extra-length shackle (not included). The roof is waterproof.

### ⚠ WARNING

- ▲ This product is intended for use by children of immature judgment and therefore adult supervision is required at all times.
- ▲ The Storage unit is not a play structure.
- ▲ Do not climb on shelf or roof.
- ▲ This item is heavy. Use care during installation to avoid back injuries.
- ▲ Unit may settle overtime. Periodically inspect unit for stability, and adjust feet as necessary.

### ⚠ CAUTION

- ▲ Unit must be levelled prior to use to ensure stability and proper latching.
- ▲ Levelling pads (provided) must be used if unit is placed on soft or uneven surfaces.
- ▲ Do not stack levelling pads more than four high.
- ▲ When doors are open, latch them against the side of the unit to prevent children from playing with them.
- ▲ Do not place heavy objects on the roof where they may fall off.

### Assembly

Your shipment contains:

One Outlast storage unit, six levelling pads, one spirit level, and this product guide.

**If your shipment is incomplete, please call customer service. All of our packaging is recyclable (cardboard and LDPE). Please recycle in accordance with local guidelines.**

### Cleaning

Mud and dirt can be removed with scrub brush and water. Over time outdoors, surfaces may blacken with mildew. Remove with detergent or a disinfectant solution such as Milton Sterilising Fluid.

### Maintenance

Acetylated wood weathers to a natural silver grey if left untreated outdoors. If you prefer the original look, scrub with a mild detergent or disinfectant solution. When dry, apply a tinted, nontoxic penetrating stain. Refinishing stain is available from customer service.

Periodically check that unit is stable and level. Adjust front levelling feet to align doors.

Periodically inspect for splinters, broken or loose parts, and/or malfunctions. Remove from service when any condition develops that might make operation unsafe.

### Construction

The wooden components are manufactured from long lasting acetylated wood and finished with a tinted nontoxic stain. All edges and corners are rounded for safety and ease of cleaning. Stainless steel hardware is used throughout and plastic components are formulated to ensure long life in sun, or varying temperature conditions. The roof has no sharp edges and is built from solid wood mouldings with a plastic underlayment to ensure maximum strength as well as waterproofing.

### User Modifications

We are not responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

### Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**



# Installation instructions

## ⚠ WARNING


▲ Storage unit is large and heavy. Use care manoeuvring into location. For proper function of doors and latch, unit must be level and stable.

1. Choose a level site.
2. If installing on soft ground, use levelling pads under each foot. (If installing on a hard, even surface, no levelling pads are needed.)

To place levelling pads, carefully pry up one corner at a time (two people needed) and place one pad under each foot as shown



3. Using a spirit level, check to make sure the Unit is not sloped in any direction. Check both side-to-side and front-to-back.



Levelling Tip: The bubble in the level indicates if your unit is sloping. The bubble will always slide toward the highest point, so add height to the opposite corner until the bubble comes to rest in the centre of the glass, between the two lines.

4. Additional levelling pads can be stacked under corners that are too low (do not exceed 4 high).
5. To fine-adjust, turn the adjustable feet to raise or lower individual corners. If more than 2 cm of thread is showing above the foot, use another levelling pad.
6. When your unit is level, the top corners of the doors will line up. This will allow the latch to function properly.

